-1

Distributed splice

Crossed wiring without connection

Splice

Removable connection

Ground

Connector

Female connector

Male connector

Entire component

Part of a component

Component case directly attached to metal part of vehicle (ground)

Component with screw terminals



Connector attached to component



Connector attached to component lead (pigtail)



Resistance wire

Resistor or heating element

Potentiometer (pressure or temperature)

Potentiometer (outside influence)

Battery