
1
2
3
4
5
6
7
8
A
B
C
D
E
F
C122
Speed control servo (9C735)
C1081
A/C compressor cycling switch (19E561)
C1032
Heater blower motor resistor, front (19A706)
C125
Windshield wiper motor (17508)
Battery Junction Box (BJB) (14A003)
C144
C146
C1031
Heater blower motor (19805)
C137
Windshield washer pump motor (17618)
C1035
Battery Junction Box (BJB) (14A003)
C1100a
Battery (10655)
G105
G106
14290
C126
ABS test connector
C1043
Park/turn lamp, right front (13411)
G101
G102
C1023
Park/turn lamp, left front (13411)
C1030
Daytime Running Lamps (DRL) module
C1041
Headlamp, right (13008)
C162
Fog lamp, right front (15200)
C160
Wheel speed sensor, right front (2C204)
Auxiliary relay box 1
C102a
Generator
G103
G104
G107
C131
Horn (13832)
C132
Ambient air temperature sensor (19E702)
C1029
EVAP canister purge valve
C152
Fog lamp, left front (15200)
engine compartment