-1


Instrument Panel and Console 501-12-00
Entertainment System – General Information 415-00-00
Instrument Cluster 413-01-00
Instrument Cluster and Panel Illumination 413-00-00
Climate Control System – General Information 412-00-00
Fuel Charging and Controls – 303-04-00
Anti–Theft – Active 419-01A-00
Electronic Compass 419-11-00
Starting System 303-06-00
Anti–Theft – Passive 419-01B-00
Roof Opening Panel 501-17-00
Engine Ignition 303-07-00
Warning Devices 413-09-00
Rear View Mirrors 501-09-00
Electronic Engine Controls 303-14-00
Automatic Transaxle/ Transmission External Controls 307-05-00
Interior Lighting 417-02-00
Seating 501-10-00
Vehicle Speed Control 310-03-00
Wipers and Washers 501-16-00
Module Communications Network 418-00-00
Exterior Lighting 417-01-00
Exterior Lighting 417-01-00
Daytime Running Lamps 417-04-00
Charging System – General Information 414-00-00
Anti–Lock Control 206-09-00
Glass, Frames and Mechanisms 501-11-00
Handles, Locks, Latches and Entry Systems 501-14-00
Occupant Restraints – Active 501-20A-00
Automatic Trans-mission/Transaxle 307-01-00
Occupant Restraints – Passive 501-20B-00
Multifunction Elec-tronic Control Modules 419-10-00
Horn 413-06-00
Brake System – General Information 206-00-00
Four–Wheel Drive System 308-07A-00