C13

14401



F10052

P91
Central Junction
Box (CJB)

Pin	Circuit	Circuit Function
1	15-DA1 (GN/YE) +	Voltage, ignition switch in Start or Run (not overload protected)
	15-DA2 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected)
	50-BB12 (GY)	Voltage, ignition switch in Start (not overload protected)
2	15-CF6 (GN/YE)	Voltage, ignition switch in Start or Run (not overload protected)
	91S-KA29 (BK/YE)	Ground, switched
	15-CE8 (GN/RD) +	Voltage, ignition switch in Start or Run (not overload protected)
	15-CF6 (GN/YE)	Voltage, ignition switch in Start or Run (not overload protected)
3	31S-BB16A (BK/RD)	Ground, switched
	31S-BB16 (BK/RD)	Ground, switched
	91S-GJ7 (BK/BU)	Ground, switched
4	50-BB12 (GY)	Voltage, ignition switch in Start (not overload protected)
	29-AH14 (OG/YE)	Voltage supplied at all times (overload protected)
5	30-BB9 (RD) +	Voltage supplied at all times (not overload protected)
	30-BB9A (RD)	Voltage supplied at all times (not overload protected)
	50-BB17 (GY/OG)	Voltage, ignition switch in Start (not overload protected)
6	31S-BB16 (BK/RD)	Ground, switched
7	75-DA4 (YE/GN) +	Voltage: Ignition switch in Accessory or Run
	75-MD15 (YE/GN)	Voltage: Ignition switch in Accessory or Run
	75-DA4 (YE/GN)	Voltage: Ignition switch in Accessory or Run
	75-GG14 (YE/BU) +	Voltage: Ignition switch in Accessory or Run
	75-MD15 (YE/GN)	Voltage: Ignition switch in Accessory or Run
8	31S-HB31 (BK/OG)	Ground, switched
9	75-GG14 (YE/BU) +	Voltage: Ignition switch in Accessory or Run
	75-MD15 (YE/GN)	Voltage: Ignition switch in Accessory or Run
10	29-AG12 (OG/BK)	Voltage supplied at all times (overload protected)