C3177

14B079

T12
Power choke 1



F12103

Pin	Circuit	Circuit function
1	–	not used
2	–	not used
3	–	not used
4	–	not used
5	–	not used
6	–	not used
7	1564 (RD)	Coil, switched power
8	–	not used
9	–	not used
10	–	not used
11	–	not used
12	1564 (RD)	Video cassette player

C3178

14B079

T13
Power choke 2



F12103

Pin	Circuit	Circuit function
1	–	not used
2	–	not used
3	–	not used
4	–	not used
5	–	not used
6	–	not used
7	829 (WH/VT)	Coil, switched power
8	–	not used
9	–	not used
10	–	not used
11	–	not used
12	829 (WH/VT)	Rear Seat Entertainment (RSE) module