21-1 IGNITION SYSTEM

2001 POSTAL EXPLORER

For diagnostic information, refer to the Powertrain Control/Emissions Diagnosis Manual.



Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.