C434

14407

B19
Fuel sender
(9H307)



F04124

Pin	Circuit	Circuit Function
1	–	not used
2	8-GA25 (WH/BU)	Sensor signal
3	9-GA25 (BN/BU)	Sensor signal return (reference/ground)
4	–	not used

C435

14407

B113
Fuel tank pressure
transducer sensor
(9C968)



F03098

Pin	Circuit	Circuit Function
1	7-RJ13 (YE/VT)	Voltage D.C. supplied at all times (sensor)
2	9-RJ13 (BN/WH)	Sensor signal return (reference/ground)
3	8-RJ13 (WH/VT)	Sensor signal