
Distributed splice


Crossed wiring without connection

Splice

Removable connection

Ground

Connector

Female connector

Male connector

Entire component

Part of a component


Component case directly attached to metal part of vehicle (ground)

Component with screw terminals


Connector attached to component


Connector attached to component lead (pigtail)

Resistor or heating element

Potentiometer (pressure or temperature)


Potentiometer (outside influence)

Battery

Fuse

Circuit breaker

Heating element, Conductor loop