-18


manual transmission
A147
Powertrain Control
Module (PCM)
84
C175
136
18 DB/YE
2
C1107
B110
Output shaft speed
sensor (OSS)
1
C1107
359
18 GY/RD
303–14–00–10
B234
Digital Transmis-
sion Range (DTR)
sensor
2
C167
359
18 GY/RD
automatic transmission
A147
Powertrain Control
Module (PCM)
84
136
18 DB/YE
1
C193
B110
Output shaft speed
sensor (OSS)
2
C193
359
18 GY/RD
59
C175
134
18 GY/OG
1
C164
B235
Intermediate Shaft
Speed (ISS) sen-
sor
2
C164
359
18 GY/RD
S144
359
18 GY/RD
303–14–00–10