


**C503**

**LF DOOR LOCK SWITCH**

| PIN | CIRCUIT | CIRCUIT FUNCTION |
|---|---|---|
| 1 | – | NOT USED |
| 2 | 119 (PK/YE) | Door Lock Switch Unlock |
| 3 | – | NOT USED |
| 4 | 797 (LG/VT) | Power (Hot at All Times) |
| 5 | – | NOT USED |
| 6 | 120 (PK/LG) | Door Lock Switch Lock |
| 7 | – | NOT USED |




**C603**

**RF DOOR LOCK SWITCH**

| PIN | CIRCUIT | CIRCUIT FUNCTION |
|---|---|---|
| 1 | – | NOT USED |
| 2 | 120 (PK/LG) | Door Lock Switch Lock |
| 3 | – | NOT USED |
| 4 | 797 (LG/VT) | Power (Hot at All Times) |
| 5 | – | NOT USED |
| 6 | 119 (PK/YE) | Door Lock Switch Unlock |
| 7 | – | NOT USED |