29-1 TRANSMISSION CONTROLS (5R55E)

For diagnostic information, refer to Section 307-01 of the Workshop Manual.