

C467 (BLACK)
FUEL PUMP MODULE

PIN	CIRCUIT	CIRCUIT FUNCTION
1	926 (LB/OG)	Fuel Pump Module to PCM
2	57 (BK)	Ground
3	922 (WH/RD)	Fuel Pump Return
4	–	NOT USED
5	–	NOT USED
6	–	NOT USED
7	238(DG/YE)	Fuel Pump Module to PCM
8	–	NOT USED
9	866 (WH)	Fuel Pump Inertia Switch to Module
10	225 (BK/YE)	Fuel Pump Power

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C251	14-4
C255	63-7