## C2154

### 14A032

Turn relay, left




| Pin | Circuit | Circuit function |
|---|---|---|
| 30 | 374 (DB/WH) | Voltage supplied at all times (overload protected) |
| 85 | 57 (BK) | Ground |
| 86 | 3 (LG/WH) | Turn lamps, feed, left front |
| | 3 (LG/WH) | Turn lamps, feed, left front |
| 87 | 380 (VT/YE) | Turn relay, left, output |
| 87A | – | not used |

## C2155

### 14A032

Turn relay, right




| Pin | Circuit | Circuit function |
|---|---|---|
| 30 | 378 (BN/YE) | Voltage supplied at all times (overload protected) |
| 85 | 57 (BK) | Ground |
| 86 | 2 (WH/LB) | Turn lamps, feed, right front |
| | 2 (WH/LB) | Turn lamps, feed, right front |
| 87 | 379 (BN/WH) | Turn relay, right, output |
| 87A | – | not used |