C111 (BK)

9H589

Coil On Plug (COP)
1 (12029)

F02109

Pin	Circuit	Circuit function
1	1024 (LG/WH)	Coil On Plug (COP) 1 (12029), control
2	296 (WH/VT)	Voltage supplied in Start and Run (overload protected)

C112 (BK)

9H589

Coil On Plug (COP)
2 (12029)

F02109

Pin	Circuit	Circuit function
1	1030 (DG/VT)	Coil On Plug (COP) 2 (12029), control
2	296 (WH/VT)	Voltage supplied in Start and Run (overload protected)

C113 (BK)

9H589

Coil On Plug (COP)
3 (12029)

F02109

Pin	Circuit	Circuit function
1	1025 (OG/YE)	Coil On Plug (COP) 3 (12029), control
2	296 (WH/VT)	Voltage supplied in Start and Run (overload protected)

C114 (BK)

9H589

Coil On Plug (COP)
4 (12029)

F02109

Pin	Circuit	Circuit function
1	1028 (WH/PK)	Coil On Plug (COP) 4 (12029), control
2	296 (WH/VT)	Voltage supplied in Start and Run (overload protected)

C115 (BK)

9H589

Coil On Plug (COP)
5 (12029)

F02109

Pin	Circuit	Circuit function
1	1026 (PK/WH)	Coil On Plug (COP) 5 (12029), control
2	296 (WH/VT)	Voltage supplied in Start and Run (overload protected)

C116 (BK)

9H589

Coil On Plug (COP)
6 (12029)

F02109

Pin	Circuit	Circuit function
1	1021 (LG/YE)	Coil On Plug (COP) 6 (12029), control
2	296 (WH/VT)	Voltage supplied in Start and Run (overload protected)