

C2004
RESTRAINTS CONTROL MODULE (RCM)

PIN	CIRCUIT	CIRCUIT FUNCTION
1	–	NOT USED
2	1257 (WH/LB)	Driver Side Air Bag Feed
3	1258 (BN/LB)	Driver Side Air Bag Return
4	–	NOT USED
5	1259 (WH/YE)	Passenger Side Air Bag Feed
6	1260 (BN/YE)	Passenger Side Air Bag Return
7	–	NOT USED
8	1261 (WH/LG)	Driver Side Sensor Feed
9	1262 (BN/LG)	Driver Side Sensor Return
10	1263 (WH)	Passenger Side Sensor Feed
11	1264 (BN)	Passenger Side Sensor Return

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C228	14-3
C238	62-6
C242	13-29
C243	13-28