C432

14A005



F06177

9L468



F06161

C433 (BK)

14407

A240
Fuel pump module



F04124

Pin	Circuit	Circuit Function
1	15S-RG2A (GN/OG)	Voltage, ignition switch in Start or Run (not overload protected), Switched
2	8-GA7 (WH/RD)	Sensor signal
3	9-GA7 (BN/RD)	Sensor signal return (reference/ground)
4	31S-RG2A (BK/RD)	Ground, Switched

C434

14407

B19
Fuel sender



F04124

Pin	Circuit	Circuit Function
1	–	not used
2	8-GA25 (WH/BU)	Sensor signal
3	9-GA25 (BN/BU)	Sensor signal return (reference/ground)
4	–	not used