CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C243	13-28
C246	13-26
C259	85-3



Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.