## Multifunction switch

### Component testing procedure

| Circuit to test | Connect self–powered test light or ohmmeter to terminals | Move switch to these positions | A good switch will indicate |
|---|---|---|---|
| **Flash–to–pass** | 4 and 2 | Neutral | Open circuit |
| | | High beam | Open circuit |
| | | Headlamp flasher | Closed circuit |
| **High beam** | 5 and 2 | Neutral | Open circuit |
| | | High beam | Closed circuit |
| | | Headlamp flasher | Open circuit |
| **Low beam** | 5 and 3 | Neutral | Closed circuit |
| | | High beam | Open circuit |
| | | Headlamp flasher | Closed circuit |
| **Turn signal LH side** | 49A and 8 | Neutral | Open circuit |
| | | Flash left (no detent) | Closed circuit |
| | | Left turn | Closed circuit |
| **Turn signal RH side** | 49A and 9 | Neutral | Open circuit |
| | | Flash right (no detent) | Closed circuit |
| | | Right turn | Closed circuit |
| **Hazard flasher switch** | 49 and 11 | Neutral | Closed circuit |
| | | Hazard On | Open circuit |
| | 49 and 10 | Neutral | Open circuit |
| | | Hazard flasher switch | Closed circuit |
| | 49A and 8 | Neutral | Open circuit |
| | | Hazard flasher switch | Closed circuit |
| | 49A and 9 | Neutral | Open circuit |
| | | Hazard flasher switch | Closed circuit |
| **Ground** | 31 and 7 | | Closed circuit |