C435 (WH)

14A318



F18005

14659



F18007

C438 (BK)

14A318

R19
Rear window defrost grid

F01015

Pin	Circuit	Circuit Function
1	HF02 (BK)	Rear window defrost relay, switched output

C501

14B188

Y28
Speaker, left front



F02263

Pin	Circuit	Circuit Function
1	RA50 (GY/BU)	Speaker, left front
	RA40 (GY/BU)	Speaker, left front
2	RA51 (YE/BU)	Speaker, left front
	RA41 (YE/BU)	Speaker, left front

C439 (BK)

13N850

R19
Rear window defrost grid

F01005

Pin	Circuit	Circuit Function
1	HFE2 (BK)	Ground