C297

19D887

A97
Heater blower control module



F05089

Pin	Circuit	Circuit function
1	8-FA45 (WH/BU)	Sensor signal
2	9-FA45 (BN/BU)	Sensor signal return (reference/ground)
3	10-FA45 (GY/VT)	Signal 2 (Y–direction, reverse, downward)
4	31S-FA18 (BK/RD)	Ground, Switched
5	31-FA45 (BK)	Ground

C300

13K702



F12075

14A005



F12083

C301

14A005

A151
Antenna



F01012

Pin	Circuit	Circuit function
1	15S-HB19 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected), Switched