## C267

**14B242**

N408
Steering column lock




F04143

| Pin | Circuit | Circuit Function |
|---|---|---|
| 1 | 31-GL58 (BK) | Ground |
| 2 | 75-GL58 (YE/GN) | Voltage: Ignition switch in Accessory or Run |
| 3 | 5-GL58 (BU/BK) | Data link, bus negative |
| 4 | 4-GL58 (GY/OG) | Data link, bus positive |