
Hot at all times
Battery Junction Box (BJB)
F1.4
40A
Central Junction Box (CJB) (14A067)
Hot in Run/Start
F2.10
10A
Rear window defrost relay
Hot at all times
F2.20
5A
F2.7
15A
Directs current to power mirror motors, and controls mirror movement
Exterior rear view mirror switch (17B676)
Instrument cluster, inboard (10849)
Driver memory seat module (14C718)
Reversing current in two bi-directional motors enables mirror to move both horizontally (left and right) and vertically (up and down).
M
Exterior rear view mirror, left (17683)
M
Exterior rear view mirror, right (17682)