

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C220	31-3
C338	117-5

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.