C4162

19B113

Y291
Subwoofer, luggage compartment right



F04345

Pin	Circuit	Circuit function
1	176 (PK/LG)	Subwoofer amplifier, luggage compartment right outboard, to, Subwoofer, luggage compartment right, +
2	189 (TN/LB)	Subwoofer amplifier, luggage compartment right inboard, to, Subwoofer, luggage compartment right, +
3	179 (OG/RD)	Subwoofer amplifier, luggage compartment right outboard, to, Subwoofer, luggage compartment right, –
4	187 (DB/OG)	Subwoofer amplifier, luggage compartment right inboard, to, Subwoofer, luggage compartment right, –