5.0L


FROM BATTERY JUNCTION BOX
PAGE 13-5
J
34 LB/OG
151–8 A6
C115M
C115F
34 LB/OG
S142
34 LB/OG
34 LB/OG
34 LB/OG
34 LB/OG
34 LB/OG
151–10 D3
C116M
C116F
34 LB/OG
C182F
C182M
HEATED OXYGEN SENSOR (HO2S) # 21
PAGE 25-6
34 LB/OG
C180
4
4R70W TRANSMISSION
PAGE 30-4
34 LB/OG
C169F
C169M
HEATED OXYGEN SENSOR (HO2S) # 11
PAGE 25-6
34 LB/OG
C181F
C181M
HEATED OXYGEN SENSOR (HO2S) # 12
PAGE 25-5
34 LB/OG
C173F
C173M
HEATED OXYGEN SENSOR (HO2S) # 22
PAGE 25-5
C184
EGR VACUUM REGULATOR (EVR) SOLENOID
PAGE 25-4