R1.201
Dash Harness

Washer pump relay



Pin	Circuit	Circuit Function
A	950 (WH/BK)	Windshield washer control switch feed
B	—	Not used
C	686 (TN/RD)	Module, GEM to front washer pump relay-input
E	941 (BK/WH)	Windshield washer pump motor feed
F	460 (YE/LB)	Horn switch feed

R1.202
Dash Harness

Wiper speed relay



Pin	Circuit	Circuit Function
A	950 (WH/BK)	Windshield washer control switch feed
B	58 (WH)	Windshield wiper switch to windshield wiper motor
C	647 (GY/LB)	Module, GEM to front wiper speed control relay-output
E	56 (DB/OG)	Windshield wiper switch to windshield wiper motor
F	63 (RD)	Windshield wiper switch to windshield wiper motor

R1.203
Dash Harness

Wiper RN-PK relay



Pin	Circuit	Circuit Function
A	950 (WH/BK)	Windshield washer control switch feed
B	671 (LB)	Front wiper motor status to module, GEM-input
C	646 (YE/WH)	Module, GEM to front wiper run/dynamic brake relay-output
E	950 (WH/BK)	Windshield washer control switch feed
F	63 (RD)	Windshield wiper switch to windshield wiper motor

R1.204
Dash Harness

Exhaust brake relay (CAT)
Crank inhibit relay (V8)



Pin	Circuit	Circuit Function
A	640 (RD/YE)	Navigation, warning lamps feed
A	57 (BK)	Exhaust brake, ground circuit
B	—	Not used
C	329 (PK)	Navigation, crank enable relay
C	480 (VT/YE)	Exhaust brake, PCM to transmission clutch control
E	32 (RD/LB)	Starter control
E	1065 (WH/LB)	Heated driver seat-seat heater element return
F	1066 (GY/LB)	Heated driver seat-back heater element feed
F	33 (WH/PK)	Starter control to interlock module

R1.205
Dash Harness

Stop-turn relay, right



Pin	Circuit	Circuit Function
A	5 (OG/LB)	RH rear turn signal lamp
B	—	Not used
C	57 (BK)	Ground circuit
E	64 (DG)	Trailer RH turn signal
F	907 (YE/WH)	Battery feed #3 to lighting control module

R1.206
Dash Harness

Stop-turn relay, left



Pin	Circuit	Circuit Function
A	9 (LG/OG)	LH rear turn signal lamp
B	—	Not used
C	57 (BK)	Ground circuit
E	52 (YE)	Trailer LH turn signal
F	907 (YE/WH)	Battery feed #3 to lighting control module