Item	Part Number	Description
1	14305	Wiring harness – Alternator
2	7C078	Wiring harness – Automatic transmission (7C078)
3	14290	Wiring harness – Dash panel to headlamp junction
4	17A477	Wiring harness – Windshield wiper jumper
5	12B637	Wiring harness – Engine control sensor and fuel charge
6	14301	Wiring harness – Battery Output
7	14401	Main wiring harness
8	19D887	Wiring harness – Electronic Automatic Temperature Control (EATC) sub assembly
9	14B102	Wiring harness – Cylinder head sensor jumper
10	19A657	Wiring harness – Sunload sensor (19E663)
11	14402	Wiring harness – Steering column switches
12	14A005	Wiring harness – Body Main
13	15A434	Wiring harness – Side marker lamps
14	14A488	Wiring harness – Window regulator motor, passenger side front
15	14A488	Wiring harness – Window regulator motor, driver side front
16	14C691	Wiring harness – Passenger seat back
17	14A699	Wiring harness – Power seats
18	14B122	Wiring harness – Driver seat back
19	18C619	Wiring harness – Rear window heater
20	14407	Wiring harness – Fuel tank gauge sender
21	9L468	Wiring harness – Evaporative (EVAP) sub assembly
22	14C693	Wiring harness – Driver seat back

Item	Part Number	Description
23	14B719	Wiring harness – Front seat, driver side
24	14A344	Wiring harness – Trailer tow
25	13412	Wiring harness – Rear license plate lamp
26	18C463	Wiring harness – Water valve
27		Auxiliary Junction Box (AJB), underhood
28		Battery Junction Box (BJB) (14A003)
29		Central Junction Box (CJB) (14A068)
30		Auxiliary Junction Box (AJB), interior
31		Auxiliary relay box 1
32		Rear Electronic Module (REM)
33		Remote keyless entry module (15K602)
34		Front Electronic Module (FEM) (13C788)
35		Powertrain Control Module (PCM) (12A650)
36		Battery (10655)
37		Restraints control module (14B321)
38		Electronic Automatic Temperature Control (EATC) module (19980)
39		Side air bag module, right
40		Heater blower control module
41		Side air bag module, left
42		Fuel pump driver module (9H307)
43		ABS control module (2C219)
44		Instrument cluster