
One pole, two position switch
Relay with resistor across coil
Relay with diode across coil
Busbar
F3 10A
F14 10A
Indicates that fuse is supplied with power at all times
30
F9 15A
Switches that move together
Dashed line shows a mechanical connection between switches
Terminal number
Component number
Name of component
Details about component or operation
Normally open contact
When coil is energized, switch is pulled closed
"15" is supplied with battery voltage in position 2 or 3
Component connector number
N278
Ignition switch
0) Off
1) Acc
2) Run
3) Start
C37