



CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C200	58-5
C220	58-4
C221	58-4
C222	58-5
C234	58-6
C268	90-5
C269	90-5

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.