C61

12A522



F360002

Pin	Circuit	Circuit Function
1	9-RJ35 (BN/RD)	Sensor signal return (reference/ground)
	9-RN3 (BN/RD)	Sensor signal return (reference/ground)
2	9-RJ36 (BN/BU)	Sensor signal return (reference/ground)
3	7-RJ36 (YE/BU)	Voltage, ignition switch in Start or Run (not overload protected)
4	7-RJ35 (YE/RD)	Voltage, ignition switch in Start or Run (not overload protected)
	7-RN3 (YE/RD)	Voltage, ignition switch in Start or Run (not overload protected)
6	8-RJ30 (WH)	Sensor signal
7	8-RJ35 (WH/RD)	Sensor signal
8	9-RJ30 (BN)	Sensor signal return (reference/ground)
9	8-RJ36 (WH/BU)	Sensor signal
10	7-RJ30 (YE)	Voltage, ignition switch in Start or Run (not overload protected)
11	10-GL37 (GY/OG)	Signal 2 (Y–direction, reverse, downward)
12	31S-BB16 (BK/RD)	Ground, switched