


**C258**

**REAR AIR SUSPENSION SWITCH**

| PIN | CIRCUIT | CIRCUIT FUNCTION |
|---|---|---|
| 1 | – | NOT USED |
| 2 | 417 (PK/OG) | Air Suspension Switch Feed |
| 3 | 1195 (BN/OG) | Rear Fill Solenoid Control |
| 4 | – | NOT USED |
| 5 | – | NOT USED |
| 6 | – | NOT USED |
| 7 | 19 (LB/RD) | Instrument Panel Lamps Feed |
| 8 | 19 (LB/RD) | Instrument Panel Lamps Feed |
| 9 | 57 (BK) | Ground Circuit |
| 10 | 57 (BK) | Ground Circuit |

**CONNECTOR REFERENCE LIST**

| CONNECTOR | SECTION-PAGE |
|---|---|
| C200 | 13-33 |
| C242 | 13-37 |
| C909 | 65-2 |