

1
2
3
4
5
6
7
8
A
B
C
D
E
F
C218a
Steering wheel assembly
C218b
Steering wheel assembly
C2250
Steering column position switch
C222
Steering column position sensor
C202
Multifunction switch
front of vehicle
14401
C227
Steering column position motor
14401
front of vehicle
At steering column