-15


M68
Door lock motor, passenger side
6 C149
31-AA58B .35 BK
N138
Door lock/unlock switch, passenger
2 C795
31-AA39 .35 BK
N297
Window operating switch, passenger side front
4 C489
31-LH31 .5 BK
M76
Mirror motor, passenger side
5 C808
31-HB36 .35 BK
S194
N217
Seat adjust switch, passenger side front
3
6 C715
31-AH6 .75 BK
31-AH6A .75 BK
S181
31-DA12 2.5 BK
2 C43
31-DA14 .75 BK
N27
Left front seat heater switch
4 C694
31-LH29 .5 BK
N299
Window operating switch, right rear
4 C490
31-LH36 .5 BK
31-DA12 2.5 BK
S171
2 C32
8 C31
1 C46
A112
Generic Electronic Module (GEM)
5 C101
N240
Door ajar switch, passenger side front
2 C684
N28
Right front seat heater switch
4 C695
N238
Door ajar switch, passenger side rear
2 C686
R30
Front seat, RH
12 C31
31-DA16 .75 BK
31-HC11 .5 BK
31-LH43 .5 BK
31-DA10 2.5 BK
31-GL16 .35 BK
31-GL19 .35 BK
31-DA13D .5 BK
S178
31-DK20 1.5 BK
31-DA8 2.5 BK
G53