

1
2
3
4
5
6
7
8
A
B
C
D
E
F
C102b
Generator
C197B
Starter motor
(11002)
C197a
Starter motor
(11002)
G108
C110
C124
Brake fluid level
switch (2L414)
C1025
Deactivator switch
C135
ABS control module
(2C219)
C139
C100
A/C clutch solenoid
(19D269)
C1100b
Battery (10655)
C1021
Headlamp, left
(13008)
C103
Oil pressure
switch (9278)
C1078
A/C high pressure
switch (19D594)
C150
Wheel speed sensor,
left front (2C205)
engine compartment