

On engine, rear / LH side – Duratec–VE, automatic transmission

12A522 . . . . . E 3
A40 . Transmission hardware unit . . . . . C 1
A149 Inlet Manifold Runner Control (IMRC) module . . . . . B 2
B6 . . . Coolant temperature sensor . . . . . B 2
B8 . . . Throttle Position Sensor (TPS) (9B989) . . . . . B 2
B10 . . Engine Coolant Temperature (ECT) sensor (12A648) . . . . E 2
B11 . . Vehicle Speed Sensor (VSS) . . . . . E 2
B40 . . Exhaust Pressure Transducer (EPT) sensor . . . . . E 5
B44 . . Turbine shaft speed sensor (7M101) . . . . . E 1
B48 . . Heated Oxygen Sensor (HO2S) #11 (9G444) . . . . . D 5
B105 . Knock sensor 1 (6G004) . . . . . E 4
B120 . Transmission range sensor . . . . . B 1
B225 . Fuel rail pressure transducer sensor . . . . . B 3
C104 . . . . . B 2
C438 . . . . . C 1
C640 . . . . . B 5
C642 . . . . . C 5
C645 . . . . . C 1
C688 . . . . . E 4
C705 . . . . . E 5
C755 . . . . . B 4
C759 . . . . . B 2
C760 . . . . . E 1
C779 . . . . . E 2
C780 . . . . . B 4
C901 . . . . . B 3
C934 . . . . . C 5
C1023 . . . . . E 3
C1885a . . . . . D 5
C1885b . . . . . D 5
C1892 . . . . . B 2
O5 . . Generator . . . . . D 5
T2 . . . Ignition transformer . . . . . B 5
U1 . . Ignition transformer capacitor . . . . . B 5
Y13 . Idle speed control valve . . . . . B 4
Y33 . Electr. Vacuum Regulator (EVR) solenoid valve . . . . . B 4