C608 (GY)

14630

Power window motor, passenger side front (23394)



F02451

Pin	Circuit	Circuit function
1	333 (YE/RD)	Window motor, feed, Up
2	334 (RD/YE)	Window motor, feed, Down

C612 (BK)

14630/19A041

Speaker, right front (18808)

* E550



F02069

Pin	Circuit	Circuit function
1	*804 (OG/LG)	Speaker, right front (18808) +
	805 (WH/LG)	Speaker, right front (18808) +
2	811 (DG/OG)	Speaker, right front (18808) –

* with remote keyless entry

C629 (BK)

14630

Front passenger window/door lock switch



F10131

Pin	Circuit	Circuit function
1	333 (YE/RD)	Window motor, feed, Down
2	314 (TN/LB)	Window switch, feed, right front, Up
3	170 (RD/LB)	Battery voltage, hot in Run and Accessory only
4	313 (WH/YE)	Window switch, feed, right front, Down
5	334 (RD/YE)	Window motor, feed, Down
6	57 (BK)	Ground
7	*120 (PK/LG)	Door lock, feed
	124 (BN)	Door unlock, feed
8	*54 (LG/YE)	Voltage supplied at all times (overload protected)
	517 (BK/WH)	Voltage supplied at all times (overload protected)
9	*119 (PK/YE)	Door lock, feed
	123 (RD)	Door lock, input
10	57 (BK)	Ground