System Codes -11

	Actuated Systems (high current)
AA	Door locks and decklid (including: keyless entry/global closing)
AB	Four–wheel drive
AC	Headlamp leveling
AD	Power mirrors
AG	Power sliding roof
AH	Power seats
AJ	Power windows
AL	Power steering column
AM	Power doors
	Basic Systems
BA	Charge (including: ammeter/voltmeter)
BB	Start
	Chassis
CC	Ride suspension
CD	Self–levelling suspension
CE	Power steering (variable automatic power assist)
CF	Traction (including: anti–lock/brakes)
CG	Brakes
	Distribution Systems
DA	Splices distribution
DB	Busbars
DC	Circuit protection – Battery Junction Box (BJB)
DD	Circuit protection – Central Junction Box (CJB)
DE	Ground
DF	Junction block
	Distribution Systems
DG	Circuit protection – Auxiliary fuse box
DH	Distribution – Auxiliary fuse box
DJ	Auxiliary distribution
DK	Integrated components
	Data Bus Systems
EA	ACP Bus
EB	ALT Bus
EC	CAN Bus
ED	DCL Bus
EE	ISO Bus
EG	SCP Bus
	Climate Systems
FA	Climate 1
FB	Climate 2
FC	Climate, auxiliary heater
	Gauge Systems
GA	Gauges – level/pressure/temperature
GB	Miscellaneous (including: speedometer/ clock)
GC	Indicator – level/pressure/temperature
GD	Temperature
GE	Auxiliary warning
GG	Instrument cluster
GH	Trip computer
GJ	Horn
GK	Navigation Main
GL	Anti–theft
	Gauge Systems
GM	Audio warning (including: buzzers/chimes)
GN	Parking aid
GP	Vehicle emergency monitoring
	Heated Systems
HA	Auxiliary (including: air/filter/lighter)
HB	De–ice (including: ejectors/mirrors/washer jets/windows)
HC	Heated seats
	Climate 1
JA	Air bags
	Wiper/washer
KA	Wiper/washer
	Lighting
LA	Control and instrument
LB	Courtesy (glove box/hood/luggage comp./ map/recharg. flashlight/vanity)
LC	Entry (including: interior/floor/door)
LD	Fog/flood/driving
LE	Head (including: concealed/dim–dip/day-time running)
LF	Parking/marker/license/clearance
LG	Turn signal/cornering/hazard/stop/reverse
LH	Instrument illumination
LK	Switch illumination