

C606

RF WINDOW CONTROL SWITCH

PIN	CIRCUIT	CIRCUIT FUNCTION
1	–	NOT USED
2	333 (YE/RD)	Switch to Motor
3	314 (TN/LB)	Right Front Window Control
4	170 (RD/LB)	Window Lock Control
5	–	NOT USED
6	334 (RD/YE)	Switch to Motor
7	313 (WH/YE)	Right Front Window Control



C706

LR WINDOW CONTROL SWITCH

PIN	CIRCUIT	CIRCUIT FUNCTION
1	–	NOT USED
2	333 (YE/RD)	Switch to Motor
3	316 (YE/LB)	Left Rear Window Control
4	170 (RD/LB)	Window Lock Control
5	–	NOT USED
6	334 (RD/YE)	Switch to Motor
7	317 (GY/OG)	Left Rear Window Control