C2173a

14401

D55
Engine diagnostic
connector



F06283

Pin	Circuit	Circuit function
A	712 (OG)	C–Data
B	716 (YE)	R–Data
C	391 (RD/YE)	Voltage supplied in Start and Run (overload protected)
D	–	not used
E	1203 (BK/LB)	Ground
F	–	not used

C2173b

14401

D55
Engine diagnostic
connector



F06283

Pin	Circuit	Circuit function
A	712 (OG)	C–Data
B	716 (YE)	R–Data
C	391 (RD/YE)	Voltage supplied in Start and Run (overload protected)
D	–	not used
E	1203 (BK/LB)	Ground
F	–	not used

C2174

14401



F04082

(1) 900 (BK)
(2) 921 (GY/OG)

14401



F04263

(3) 922 (WH/RD)
(4) 1203 (BK/LB)