C432 (BK)

14405

E9
Lamp assembly, left rear



F03099

Pin	Circuit	Circuit Function
1	31-LF23 (BK)	Ground
2	29S-LF11 (OG/WH)	Voltage supplied at all times (overload protected), switched
3	49S-LG12 (BU)	Pulsed power feed (overload protected), switched
	15S-LG14A (GN/RD)	Voltage, ignition switch in Start or Run (not overload protected), switched

C435 (BN)

14405

E49
Turn lamp, left rear



F03099

Pin	Circuit	Circuit Function
1	31-LG12 (BK)	Ground
2	–	not used
3	49S-LG12 (BU)	Pulsed power feed (overload protected), switched

C433 (BK)

14405

E10
Lamp assembly, right rear



F03099

Pin	Circuit	Circuit Function
1	31-LF24 (BK)	Ground
2	29S-LF20 (OG)	Voltage supplied at all times (overload protected), switched
3	49S-LG19 (BU/RD)	Pulsed power feed (overload protected), switched

C436 (BN)

14405

E48
Turn lamp, right rear



F03099

Pin	Circuit	Circuit Function
1	31-LG19 (BK)	Ground
2	–	not used
3	49S-LG19 (BU/RD)	Pulsed power feed (overload protected), switched