Headlamp switch

Schematic



Terminal locations