37-1 SHIFT LOCK

2001 POSTAL EXPLORER

For diagnostic information, refer to Section 307-05 of the Workshop Manual.



Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.