| Fuse | Amps | Circuits protected |
|---|---|---|
| F4.01 | 15 | Rear Electronic Module (REM) |
| F4.02 | 5 | License lamps (13550) |
| F4.03 | 10 | Lamp assembly, left rear (13405), Side lamp, left rear (13411) |
| F4.04 | 10 | Luggage compartment lamp (13A756) |
| F4.05 | 5 | Rear Electronic Module (REM), Rear window defrost |
| F4.06 | 10 | Reversing lamp, left (13411), Reversing lamp, right (13411) |
| F4.07 | 10 | Side lamp, right rear (13411), Lamp assembly, right rear (13404) |
| F4.08 | 5 | High mounted stoplamp (13A613) |
| F4.09 | – | not used |
| F4.10 | 15 | Heated seat module, passenger side front |
| F4.11 | 15 | Heated seat module, driver side front |
| F4.12 | 5 | Rear Electronic Module (REM) |
| F4.13 | – | not used |
| F4.14 | 5 | Convertible top raise relay, Convertible top lower relay |
| F4.15 | 5 | Generator |
| F4.16 | – | not used |

| Fuse | Amps | Circuits protected |
|---|---|---|
| F4.17 | 15 | Fuel pump relay |
| F4.18 | 20 | Subwoofer amplifier (18C804) |
| F4.19 | 30 | Seat adjust switch, driver side front (14A701) |
| F4.20 | 30 | Front Electronic Module (FEM) (13C788) |
| F4.21 | – | not used |
| F4.22 | 20 | Ignition switch (11572) |
| F4.23 | 30 | SSP 4 relay |
| F4.24 | 30 | SSP 3 relay |
| F4.25 | 40 | Central Junction Box (CJB) (14A068) |
| F4.26 | 30 | Seat adjust switch, passenger side front |
| F4.27 | 30 | SSP 1 relay |
| F4.28 | 30 | Rear Electronic Module (REM) |
| F4.29 | 30 | Rear window defrost relay |
| F4.30 | – | not used |
| F4.31 | 40 | Convertible Top |
| F4.32 | 30 | SSP 2 relay |