
Hot in Start
F2.24
7.5A
Central Junction Box (CJB) (14A068) 13–6
automatic transmission
manual transmission
329 22 PK
31 C146
329 20 PK
24 C110
12 C167
33 22 WH/PK
1 C257
Clutch pedal position switch
1) Clutch pedal depressed
2) Normal position
23–11, 24–11, 25–11
2 C257
329 22 PK
31 C146
329 20 PK
24 C110
1093 20 TN/RD
4.0L
329 20 PK
Allows driver to start vehicle with transmission in Park or Neutral.
P R N D 1 2
Digital Transmission Range (DTR) sensor (7F293) 30–2
10 C167
1093
31 C110
1093 20 TN/RD
A
See page 20–1