C185 (BK)

12B637

Fuel injector 5
(9F593)



F02054

Pin	Circuit	Circuit function
1	559 (TN/BK)	Fuel injector 5, control
2	361 (RD)	Voltage supplied in Start and Run (overload protected)

C186 (BK)

12B637

Fuel injector 6
(9F593)



F02054

Pin	Circuit	Circuit function
1	560 (LG/OG)	Fuel injector 6, control
2	361 (RD)	Voltage supplied in Start and Run (overload protected)

C187 (BK)

12B637

Fuel injector 7
(9F593)



F02054

Pin	Circuit	Circuit function
1	561 (TN/RD)	Fuel injector 7, control
2	361 (RD)	Voltage supplied in Start and Run (overload protected)

C188 (BK)

12B637

Fuel injector 8
(9F593)



F02054

Pin	Circuit	Circuit function
1	562 (LB)	Fuel injector 8, control
2	361 (RD)	Voltage supplied in Start and Run (overload protected)

C192 (GY)

14290



F04371

12B637



F04269

(1) 115 (LG/BK)
(2) 904 (LG/RD)
(3) 114 (LB/YE)
(4) 36 (YE/WH)