123-1 MEMORY SEATS

2002 EXPEDITION/NAVIGATOR

For diagnostic information, refer to Section 501-10 of the Workshop Manual.

Controls the direction of current flow to operate the bi-directional motor in a clockwise or counter clockwise direction which moves the seat to the desired position.



Each Seat Motor Assembly contains 3 bi-directional motors (Front Height Motor, FWD/RWD Motor and Rear Height Motor) that drive the seat up, down, forward or rearward based on the position of the Seat Control Switches.