Wiring Harness Overview

Two–door model



Item	Part Number	Description	Item	Part Number	Description
1	12B637	Wiring harness – Wiring harness – Engine control sensor + fuel charge	15	19A044	Wiring harness – Wiring harness – Radio speaker, front LH – Four–door model
2	13A409	Wiring harness – Rear lamp jumper	16	–	5R44E Transmission
3	13A724	Wiring harness – Wiring harness – Courtesy lamp switch extension – Super cab	17	7000	5R55E Transmission
4	14290	Wiring harness – Dash panel to headlamp junction	18	2C018	ABS control module
5	14334	Wiring harness – Interior lamp, feed – Super cab	19	–	Auxiliary relay box 1
6	14401	Wiring harness – Main	20	–	Battery
7	14405	Wiring harness – Rear lamp	21	–	Battery Junction Box (BJB)
8	14630	Wiring harness – Window regulator jumper, right front door – with power equipment	22	–	Central Junction Box (CJB)
9	14631	Wiring harness – Window regulator jumper, left front door – with power equipment	23	–	Central security module
10	14A280	Wiring harness – Cable assembly – Battery	24	15A272	Daytime Running Lamps (DRL) module
11	14A320	Wiring harness – Headlamp dimmer switch, jumper	25	–	Generic Electronic Module (GEM)
12	19A041	Wiring harness – Wiring harness – Radio speaker – without power equipment	26	12A650	Powertrain Control Module (PCM)
13	19A044	Wiring harness – Wiring harness – Radio speaker, front LH – without power equipment	27	043B13	Restraints Control Module (RCM)
14	19A041	Wiring harness – Wiring harness – Radio speaker – Four–door model	28	9C735	Speed control servo