Item	Part Number	Description
1	12614	Wiring harness – Air spring suspension pressure indicator switch
2	12A581	Wiring harness – Engine control sensor
3	12B637	Wiring harness – Engine control sensor and fuel charge
4	13A006	Wiring harness – Headlamps
5	13A409	Wiring harness – Rear lamp connector
6	14014	Wiring harness – Door lock feed
7	14086	Switch and wiring assembly – Right rear window regulator control
8	14300	Wiring harness – Battery output
9	14305	Wiring harness – Alternator rectifier system
10	14335	Wiring harness – Interior illumination
11	14401	Wiring harness – Main
12	14405	Wiring harness – Tail lamps
13	14630	Wiring harness – Window regulator, right front door
14	14631	Wiring harness – Window regulator, left front door
15	14A005	Wiring harness – Body main
16	14A348	Wiring harness – Trailer brake control switch
17	14A699	Wiring harness – Power seats
18	14B060	Wiring harness – Starter motor relay and battery ground
19	14B079	Wiring harness – Console panel
20	15525	Wiring harness – Back up lamp switch to rear lamp feed
21	15A657	Wiring harness – Roof sliding panel control switch
22	15K857	Wiring harness – Park brake switch
23	18B518	Wiring harness – Heater blower motor, front
24	–	ABS control module (2C219)
25	–	Powertrain Control Module (PCM) (12A650)
26	–	Restraints control module (14B321)
27	–	Driver seat module (14C718)
28	–	Vehicle Security Module (VSM)
29	–	Central Junction Box (CJB) (14A068)
30	–	Auxiliary relay box 1
31	–	Auxiliary relay box 2
32	–	Auxiliary relay box 3
33	–	Audio Visual Navigation (AVN) module (10E887)