
* LPG
FROM BI-FUEL POWER RELAY
PAGE 22-9
ZZ
BI-FUEL RELAY MODULE
WH
151–18 F3
G074
C4014M
C4014F
LOW FLOW INJECTOR ASSEMBLY
*COOLANT SOLENOID
LOW FLOW IN-JECTOR 1
LOW FLOW INJECTOR 2
G072
G073
C4013F
C4013M
151–18 F4
G113
RR
TO RESISTOR
PAGE 22-9
G011
G013
C4035F
C4035M
(NOT USED)
C4037M
G009
S4040
HIGH FLOW INJECTOR ASSEMBLY
HIGH FLOW INJECTOR 6
HIGH FLOW INJECTOR 7
* HIGH FLOW INJECTOR 8
HIGH FLOW INJECTOR 5
HIGH FLOW INJECTOR 4
HIGH FLOW INJEC-TOR 3
SS
TO C4025
PAGE 22-14
REVISED
G001
G017
G019
G051
G053
G055
G049
G047
G045
C4025
COMPUVALVE MODULE
1
17
19
51
53
55
49
47
45
11
13