14A488 - S12

Splice Location: **F4** - Near Restraints Control Module (RCM) T/O (C310b)

1011 to Door lock switch, passenger side
1011 to Climate contr seat sw, passenger side
1011 to Climate contr seat switch, driver side
1011 to Door lock switch, driver side
1011 to 14334 Roof opening panel switch
1011 to Splice 14401-S25
1011 to Illumination dimmer
1011 to Window adjust switch, right rear
1011 to Window adjust switch, left rear
1011 to 14B079 Wdo adj sw, master left front

14A488 - S13

Splice Location: **A5** - Near RH Side D-Pillar

218 to 14401 Sunload sensor
218 to Central Security Module (CSM)
218 to Illumination dimmer

14A488 - S14

Splice Location: **F3** - Between A-Pillar and B-Pillar, LH Side

894 to Exterior rear view mirror, right
894 to Exterior rear view mirror, left
894 to 2B325 Adj pedal mry potentiometer
894 to 14C719 Driver memory seat module

14A488 - S15

Splice Location: **D3** - Near LH Side B-Pillar

118 to 14A584 Door lock actuator, right front
118 to Central Security Module (CSM)
118 to Door lock actuator, right rear
118 to Door lock actuator, left rear

14A488 - S16

Splice Location: **F2** - Between A-Pillar and B-Pillar, LH Side

891 to Exterior rear view mirror, right
891 to Exterior rear view mirror, left
891 to 2B325 Adj pedal mry potentiometer
891 to 14C719 Driver memory seat module

14A488 - S17

Splice Location: **F2** - Between A-Pillar and B-Pillar, LH Side

59 to Exterior rear view mirror, right
59 to Exterior rear view mirror, left
59 to Central Junction Box (CJB)
59 to 14401 (EATC) module (Rear defrost ind)

14A488 - S18

Splice Location: **A5** - Between A-Pillar and B-Pillar, RH Side

120 to Door lock switch, passenger side
120 to Door lock switch, driver side
120 to Liftgate door lock switch
120 to Central Security Module (CSM)

14A488 - S19

Splice Location: **E1** - LH Side Cowl Near Grommet

170 to 1173 to 15C670 Roof opng pnl mtr asy
1001 to Central Junction Box (CJB)
1001 to 14A699 Power seat switch, left

14A488 - S20

Splice Location: **F4** - Between B-Pillar and C-Pillar, LH Side

140 to 14334 Inside rear view mirror unit
140 to 14398 Digital Trans Range (DTR) sns
140 to 13B431 Reversing lamp, left
140 to Auxiliary Junction Box (AJB)
140 to Splice 13A409-S2
140 to Navigation Electronic Control Unit (ECU) mod

14A488 - S22

Splice Location: **F4** - Near Restraints Control Module (RCM) T/O (C310b)

117 to 14A584 Door lock actuator, left front
117 to 14A584 Door lock actuator, right front
117 to Central Security Module (CSM)
117 to Door lock actuator, left rear
117 to Door lock actuator, right rear

14A488 - S24

Splice Location: **A2** - Near Variable Assist Power Steering (VAPS) Module T/O (C2231a)

1001 to Central Junction Box (CJB)
1001 to Variable Assist Pwr Stng (VAPS) Mod
1001 to Variable Assist Pwr Stng (VAPS) Mod

14A488 - S27

Splice Location: **C9** - RH Passenger Door, Center

1205 to Exterior rear view mirror, right
1205 to 14A584 Door ajar switch, right front
1205 to G402 RR D pillar
1205 to Door lock switch, passenger side
1205 to Door lock switch, passenger side

14A488 - S28

Splice Location: **F8** - Near CSM T/O (C3008d)

14 to Illumination dimmer
14 to Splice 14401-S12
14 to Splice 13B431-S3
14 to Auxiliary Junction Box (AJB)
14 to Splice 13A409-S3
14 to Splice 14A583-S2
14 to Central Security Module (CSM)

Note: T/O = Take Out